


# DSLR TERMINOLOGY

View From My Lens

Even though each camera make and model is different, this guide will help you to easily identify basic parts and functions.

Perfect to print A5 size  
14cm x 21cm / 5.53" x 8.27"

## PICTURE REVIEW BUTTON



**VIEWFINDER**  
The main source for viewing the scene and menu options

**LCD WINDOW**

## DIOPTR

It allows you to customize the viewfinder so that you can see a clear focused image.

## LENS ALIGNMENT MARK

Line up the matching dots to fit the lens into the mount, and then twist until it locks.

## SHUTTER RELEASE

When pressed, the shutter of the camera is "released", so that it opens to take a picture.

## DEPTH OF FIELD PREVIEW

It helps you see potential depth of field

## HOTSHOE

The mounting point on the top of the camera to attach a flash unit.

## SHOOTING MODE DIAL

Sets the camera to your desired shooting mode.



**LCD CONTROL PANEL**

Provides information on camera settings (ISO, white balance, battery power, number of pictures left, etc.)



**BATTERY SLOT**

**TRIPOD THREAD SLOT**